

CEILING DIFFUSERS

- MAINTENANCE INSTRUCTIONS FOR SMM, SMI, EPM, EPI



FLOW PANELS

Flow panels are washable according to the washing instructions.

To remove the flow panel, simply pull out the rubber from the frame. To install the clean flow panels after washing, push the rubber into the frame – no tools are needed. Please refer to the installation guide on our website.

Washing procedure, flow panels

- Pre-rinse: 20°C (70°F) approx. 3 minutes without any detergent
- Pre-wash (if needed): 30°C (86°F) approx. 10 minutes with a laundry detergent. Quantities of detergent as recommended by the supplier.
- Wash: 30°C (86°F) approx. 20 minutes with a laundry detergent. Quantities of detergent as recommended by the supplier.
- · Rinse thoroughly after each washing
- · Do not add any softener
- · Drying: light spin-drying or hanging

Tumbling

Do NOT tumble!



PLENUM BOXES

Plenum boxes are not washable. Clean the plenum box by wiping with a damp cloth or use a portable vacuum cleaner. To protect the insulation of the plenum box, do not saturate the fabric when wiping. Use damp cloth only.

Plenum box does not have to be disassembled from the frame – only the flow panel should be removed to clean the plenum box from inside.