


## **DefrostDuct™** installation



A FabricAir® DefrostDuct<sup>™</sup> is easy to install.

For optimal performance, the FabricAir® DefrostDuct™ should not be in contact with any sharp edges, rods or the fan guard.

Some air coolers may require an adapter over the fan guard for smooth connection. The length of the adapter must be at least 10 mm [3/8"] longer than the fan motor and/or fan guard.

" To minimize risk of freezing, always install the buckle at 12:00 o'clock position.

\*\*The adapter is mounted by the air cooler manufacturer or installer; it is not a part of the FabricAir delivery.

